

Change E-Series Overhead Door Tilt (TX-E401) Battery

Read before changing batteries!

Before changing batteries, please call the monitoring station and ask them to put your system on test. For this, you will need your account information. Please note that putting your batteries in backwards may damage the device. Remember to note the battery terminals.



You will need a small Philips screwdriver (looks like an x) and a CR123A Battery

1. Locate the screw at the base of the device and unscrew.
2. Remove the cover, pulling from the side with the screw hole.
3. Gently remove the battery from the terminal.
4. Note the battery terminals (+, -). Putting Batteries in Backwards can damage the Device.
5. Place a new battery in the device (CR123A).
6. Ensuring that the hooks go in first, replace the cover on the device.
7. Screw the cover back in.