

Change Micro Door/Window Contact (TX-1012-01-1) Battery

Read before changing batteries!

Before changing batteries, please call the monitoring station and ask them to put your system on test. For this, you will need your account information. Please note that putting your batteries in backwards may damage the device. Remember to note the battery terminals.



You will need a small flat head screwdriver and a CR2032 Battery

1. Find the notches on the top corners of the device.
2. Using the screwdriver, pry off the cover of the device. The easiest way is to insert the top of the screwdriver in the notch and twist.
3. Remove the cover.
4. The device has an inner cover, remove this by popping it off with the screwdriver as well.
5. Carefully remove the circuit board.
6. Gently remove the battery.
7. Note the battery terminals (+, -). Putting in a battery reversed can damage the device.
8. Place a new battery in the device (CR2032).
9. Place the circuit board in the device and replace the inner cover.
10. Place the cover back on the device