

Change Personal Panic Device (TX-4200-01-1) Battery



Read before changing batteries!

Before changing batteries, please call the monitoring station and ask them to put your system on test. For this, you will need your account information. Please note that putting your batteries in backwards may damage the device. Remember to note the battery terminals.

You will need a small Philips screwdriver (looks like an x) and a CR1632 Battery
Your Panic May Look Like a Watch or a Necklace

1. Unscrew the bottom of the device.
2. Remove the bottom and the rubber wristband or Necklace Strap.
3. Gently remove the circuit board
4. Gently remove the battery from its connections.
5. Note the battery terminals (+, -). Putting in a battery reversed can damage the device.
6. Place a new battery in the device (CR1632).
7. Place the circuit board back in the plastic cover, ensuring the lights line up with the slots on the cover.
8. Replace the rubber wristband pieces or Necklace Strap and the base of the device.
9. Screw in the base.
10. Test the device by pressing the button. A light will blink to signal the device is operational.