

Change Plunger (ION-PLUNGER) Battery

Read before changing batteries!

Before changing batteries, please call the monitoring station and ask them to put your system on test. For this, you will need your account information. Please note that putting your batteries in backwards may damage the device. Remember to note the battery terminals.



You will need a CR1620 Battery

1. Remove the plunger gently from the door before changing the battery.
2. To remove the blue lid, squeeze, twist, and pull it off.
3. Locate the battery
4. Gently slide out the battery. You may use a flathead screwdriver if this proves difficult.
5. Note the battery terminals (+, -). Putting in a battery reversed can damage the device.
6. Place a new battery in the device (CR1620).
7. Replace the lid on the device, making sure that it is seated in all the way. Then return the device to the door