

Change Recessed Door Contact (TX-E221) Battery

Read before changing batteries!

Before changing batteries, please call the monitoring station and ask them to put your system on test. For this, you will need your account information. Please note that putting your batteries in backwards may damage the device. Remember to note the battery terminals.



You will need a small flat head screwdriver and a CR2 Battery

1. You do not need to remove the contact from inside your door to change the batteries. Insert the screwdriver into the notch on the cover of the device and pry it off.
2. Gently remove the circuit board from the device.
3. Locate the battery. Note that the battery can only be removed on one side due to the metal that holds it in place.
4. Gently remove the battery.
5. Note the battery terminals (+, -). Putting Batteries in reversed can damage the device.
6. Place a new battery in the slot (CR2).
7. Note the indents on the inside of the device. Replace the circuit board in the device by sliding it into the indents.
8. Replace the cover on the device. Press in until you hear a click.